
# WOOD FRAMING RAFTER+ Create Batten Beam Systems



#### Create Batten Beam Systems




Rafter+		
Load Families		
🥨 Create Common Rafter Systems		
🞇 Create Openings in Beam Systems		
🌾 Select all Beam Systems by Roof/Floor or Rafter/Beam		
🎇 Select Beam System(s) by Rafter(s) or Beam(s)		
🎪 Select Beam Systems by Rafter from the Same Slope		
Minsert/Update Hip/Valley Rafter		
☆ Insert/Update Ridge		
左 Insert/Update Collar Beam Systems		
🔁 Insert/Update Girder Beam		
Insert/Update Sleeper		
🗗 Insert/Update Trimmer		
🌿 Update Beam Systems		
🏀 Update Beam Systems (Check Openings)		
🜮 Create Horizontal Beam Systems on the Roof		
🜮 Create Batten Beam Systems		

Select a roof.

Select Create Batten Beam Systems from the menu.



## **Create Batten Beam Systems**




Ticked and unticked Cut beam option results



d type for non-horizontal beams:	
Beam type     M_Rafter_Batten Beam : 50x50       Width (b)     50x00       Depth (h, d)     50x00	Hostortal z.Direction justification of beame Top Ototom Cut beam ends
Spacing Fixed spacing 600.00	
Position Place on the top Place at the bottom	Cut beam ends
	OK Cancel

- Select batten beam type from existing structural framing families in the project.
- Select the direction of beams.
- Select z-Direction justification of beams.
- Tick the *Cut beam ends* checkbox if necessary.
- Enter a value to fixed Batten spacing.
- Select placement of rafters. They can be placed on the top or at the bottom of the roof, and click OK.

## Create Openings in Batten Beam System



AGACAD

TOOLS 4 BIM


Select Batten Beam System.

Select the **Create Openings in Beam Systems** function from the menu.

#### Frame Openings in Batten Beam System

to the nearest batten


beam.



AGACAD

Select Batten Beam Systems.

- Select the **Frame Openings (by Face)** function from the menu.
- After framing is completed, select batten beam systems again, and run the function **Update Beam Systems** to update joints and cuts.



AGA CAD Ltd T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com