METAL FRAMING RAFTER+ Load Families




Load Rafter Families

	Rafter+M		
	Load Famili	es	
10	ading families	and schedules	
	Loading family -	C:\ProgramData\Tools 4 Revit\Rafter+M \Metric Library\M_Rafter_Common Rafter_M.fa	

- The command Load Families loads structural framing families and sample schedule tables for framing elements into the project.
- To avoid this time-consuming operation, the user can save file as a template after loading families.



Load Families – Schedules




<framing member="" schedule=""></framing>							
Α	B	С	D	E	F		
Framing Member	Framing Membe	FM SortMark	Cut Length	Count	Volume		
Collar Beam							
Collar Beam	Beam	SJ1	15267	3	0.14 m ³		
Collar Beam: 3		·	15267		0.14 m ³		
Common Rafter							
Common Rafter	Rafter		321014	115	3.21 m ³		
Common Rafter: 115		·	321014		3.21 m ³		
Double Collar Beam							
Double Collar Beam	Beam		31177	9	0.56 m ³		
Double Collar Beam	Rafter	•	73634	14	0.96 m ³		
Double Collar Beam: 23		·	104811		1.52 m ³		
Ridge Board							
Ridge Board	Rafter	HR11	7035	1	0.16 m ³		
Ridge Board: 1			7035		0.16 m ³		
Grand total: 142			448127		5.03 m ³		


- The command Load families loads sample schedules to the project.
- These schedules include a number of predefined shared parameters which are assigned to framing members
- The user can use schedules to search and filter different framing members and elements.
- The user can edit properties of schedules if necessary and use them in the project.


	<framing member<="" th=""><th>er - Mark Definitions></th><th></th></framing>	er - Mark Definitions>		
Α	В	C	D	
Framing Member	Framing Member Type	Framing Member Description	Framing Member Mark	
Collar Beam	Beam	Stub Joist	SJ	
Common Rafter	Rafter	Rafter	R	
Double Collar Beam	Beam	Collar Beam	CB	
Double Collar Beam	Rafter	Hip Rafter	HR	
Double Collar Beam	Beam	Stub Joist	SJ	



The Command Load Families Loads:








- Structural Framing families of roof elements;
- Single profile families and double profiles families.
- You can modify double profiles to make it boxed or open configuration using type options.


Note: Family name begins with "I_Rafter_" for imperial units and with "M_Rafter_" for metric units.

Load Additional Rafter Types

• To load additional rafter types, use **Load Family** command from Revit menu.



BUILDING BIM TOGETHER | www.aga-cad.com



AGA CAD Ltd T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com