



Create Common Rafter Systems







- Select roof;
- Select the Create Common Rafter Systems function from "Rafter+" menu.


NOTE: Load Families to your project before starting *Create Common Rafter System* command.



Configure Beams







- Now you can choose End cut type of the rafter;
- Enter the End cut height dimension h1 if required;
- Select framing family available in the project for Rafter beam;
- Enter the distance of Fixed Rafter spacing;
- Select position of Rafter beam.


NOTE:

You can change all these parameters at any time.




Configure Beams


Placed on the top




Placed at the bottom











Change View Settings








- You can make a roof material transparent for the best view and easier work with roof and rafters.
- Now it is the best time to edit distribution of rafters in all slopes.



Edit Distribution of Rafters








Beginning

End

- Select Rafter systems
- Select Justification option
 - Beginning
 - End
 - Center (default)
 - Direction line





Center





Edit Distribution of Rafters






- You can define a precise distance between rafters and the slope side using the *Split Beam System* function of Rafter+.
- To avoid mistakes and improve performance, it is recommended to use this function only after the framing of the roof is finished.

For more information please see the document about the *Split Beam System* function.




Edit Rafter Systems





- You can easily recover deleted elements of rafter systems:
 - Select Rafter systems;
 - In the ribbon, click the Edit Boundary tool;
 - Click Reset System and then Finish Beam System.





AGA CAD Ltd

T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com