




METAL FRAMING RAFTER+
Insert/Update Trimmer

AGACAD
TOOLS 4 BIM

Insert Trimmer








- Select any rafter to insert a trimmer.
- Select the **Insert/Update Trimmer** function from the menu.




AGACAD TOOLS 4 BIM


Insert Trimmer




- Select Trimmer beam type from structural framing families existing in the project.
- Select Trimmer placement - place on the selected beam start/bottom or end/top point.
- Choose Rotation of trimmer.


Insert Trimmer







- Indicate Z-Direction position.
- Indicate Position in beam system.






Insert Trimmer







- Select start and end cuts




Update Trimmer





- Select a trimmer you want to update.
- Select the **Insert/Update Trimmer** function from the menu.
- Make your changes in Trimmer window, and click OK.



AGA CAD Ltd
T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com