




WOOD FRAMING RAFTER+
Insert/Update Hip/Valley Rafter



Create New Hip/Valley Rafter



- Select two rafter systems in adjacent slopes.
- Select the *Insert/Update Hip/Valley Rafter* function from the menu.





Configure Hip/Valley Rafter





- Now you can choose End cut type of the rafter;
- Enter the End *cut height* dimension **h1** if required;
- Select framing family available in the project for Rafter beam.

Update Existing Hip/Valley Rafter



- Select the hip/valley rafter or multiple hip/valley rafters you want to update.
- Select the *Insert/Update Hip/Valley Rafter* function from the menu.
- Make your changes to End cut type of the rafter or Cross section dimensions, and click OK.





AGA CAD Ltd

T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com