




# TOOLS 4 BIM DOCK INSTALLATION & ACTIVATION GUIDE

Standalone License Activation Instruction






# Before Activation

1. Make sure your computer has Internet connection;
2. Make sure that your firewall is not blocking outgoing communication from Revit processes.


# Activation Instructions

1. Go to “Store” → “My Tools”;
2. Enter activation code to “Activate”.

All products which are included to activation code will be automatically activated and the products will appear under “My Tools”. You will need to install them all or individually:





After installing you will see expiration date for every product and will be able to use them in your projects.



# Report on Trial or Permanent Licenses

You can find detailed report with activated licenses under “Options” → “Standalone Licenses”:





ENJOY WORKING WITH OUR PRODUCTS!

AGA CAD Ltd

T: +370 618 55671 | E: [support@aga-cad.com](mailto:support@aga-cad.com) | W: [www.aga-cad.com](http://www.aga-cad.com)