TOOLS4BIM DOCK
INSTALLATION & ACTIVATION GUIDE

Standalone License Activation Instruction

AGACAD
TOOLS 4 BIM

Before Activation

1. Make sure your computer has active Internet connection;

2. Make sure that your firewall is not blocking outgoing communication from Revit processes.

Activation Instructions

1. Open solution tab and click **Install**;

2. Enter activation code to "Activate".

All products that are bound to the activation code will be automatically activated and the products functions will be visible when product is selected.

After installation, you will be able to use every owned product in your projects and see each product's expiration date next its name.

Report on Trial or Permanent Licenses

You can find detailed report with activated licenses under "Support" button:

ENJOY WORKING WITH OUR PRODUCTS!

AGA CAD Ltd
T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com