




## **Create Openings**












- Select beam system where openings are located.
- Select command Create Openings in Beam Systems.

## NOTE:

Openings must be created from linear elements.
Cut of Beam system is done according to openings top face boundary.




## **Create Openings**










 If opening position changes, just repeat the function Create Openings lin Beam Systems and beam systems will be updated according to new openings positions.

## NOTE:

If you want to update beam systems according to openings and you also need to change the beam system end cut or cross-sectional dimensions and update joints and cuts, then select the *Update Beam Systems (Check Openings)* function.





AGA CAD Ltd

T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com